

LAMINATE MAINTENANCE

You can immediately walk on your new **Laminate floor** after installation.

1. You can walk on the floor during and immediately after installation, ensure that humidity in the room is always at least 50%, use a humidifier if you need to.
2. For dry maintenance, we advise a dry mop or vacuum cleaner, make sure the vacuum cleaner is equipped with soft wheels and a special parquet brush to avoid scratches on your floor.
3. Slightly damp maintenance is allowed, wet maintenance is absolutely forbidden. Also we recommend never using a steam cleaner.
4. Remove any water immediately.
5. Protect furniture and chair legs, avoid bringing dirt, water and sand indoors by providing a suitable floor mat at the door. Use (office) chairs and seats with soft wheels that are suitable for a laminate floor and/or use a suitable desk mat.
6. Never drag items of furniture over the floor, but lift them up.
7. The smooth surface of your laminate floor will not retain dirt or dust. Remove stubborn stains carefully with acetone or nail polish remover. Never use scouring products! Never use wax or varnish coating on the floor.